

MOISTURE INDICATOR FOR WOOD AND BUILDING MATERIALS BDD Mini

APPLICATIONS & FEATURES

The BDD "mini" pin- moisture meter used by Constructors, House Inspectors, Wood-workers, and Homeowners for rapid detection of moisture content in wood- and construction materials.

The BDD "mini" is very easy to use and powerful to detect, track and locate moisture levels, moisture related problems, dampness and leaks in walls, floors and roofs.

Applications:

- Detect dampness and related moisture problems
- Check surface moisture before painting, varnishing and other surface treatments
- Locate/track source for leaks and dampness
- Classify construction materials as wet/dry
- Check moisture level in wood materials, cement, concrete, mortar, plaster, asbestos boards and bricks
- Use measuring result from a "dry" area as reference value

TECHNICAL SPECIFICATION	BDD-Mini
MATERIALS	Wood- Building Materials
MEASURING PRINCIPLE	Resistance type
MEASURING RANGE	Wood: 6- 60 % H ₂ O Building material: 6 60% H ₂ O
ACCURACY	Wood 6-60 % ± 1.5 %
BATTERY WARNING	Yes
DISPLAY	LCD 3 ½ digits
RESOLUTION	0.1 %
BATTERY	12 V Alkaline
SIZE (L x H x D)	75 x 38 x 15 mm
WEIGHT (INCL BATTERY)	35 g
WARRANTY	1 Year

The BDD Mini is delivered with battery ready to use.

